

HF-03 sada handsfree



Obsah balení

- jednotka Handsfree s přípojovacím konektorem
- mikrofon s konektorem
- drobný instalační materiál

Instalace

Jednotka: vyberte vhodné umístění pro instalaci jednotky HF-03. Vhodné je takové místo, aby přední strana handsfree s reproduktorem směřovala co nejvíce do prostoru (u vozu směrem k řidiči). Nevhodné umístění může výrazně utlumit hlasitost reproduktoru. Při výběru umístění mějte také na paměti délku přívodních vodičů. Jednotku upevněte pomocí přiložené samolepky na dobře odmaštěný povrch. Vodič s šestipólovým RJ konektorem přiveďte k jednotce autoalarmu či GSM komunikátoru a připojte do konektoru určeného pro připojení handsfree.

Mikrofon: vyberte vhodné místo pro mikrofon. U vozidel je optimální vzdálenost cca. 40 – 50 cm od řidičových úst. Pro uchycení mikrofonu je možno použít přiložený klips. Kabel svedte k jednotce a připojte ho do konektoru na boční straně jednotky handsfree.

Nastavení

Tahový potenciometr na jednotce handsfree nastavte vždy na maximum. Citlivost mikrofonu a hlasitost reproduktoru je možno upravit pomocí nastavovacích parametrů výrobku, ve kterém je HF-03 připojeno.

Sada HF-03 slouží k rozšíření funkcí autoalarmu CA-120x Athos nebo GSM komunikátoru GD-06 o možnost telefonování. Instalací této sady k autoalarmu získáte možnost přijímat hovory z libovolných telefonních čísel a možnost volání až na 4 přednastavená telefonní čísla. V době poplachu je možno pomocí sady odposlouchávat prostor vozu a případně i komunikovat s narušitelem. Obsluha handsfree je blíže popsána v manuálu autoalarmu. Sada HF-03 je určena k instalaci do interiéru vozu. Handsfree je aktivováno v případě, že je voláno z vozu nebo pokud je přijímán příchozí hovor (napájení řízeno z autoalarmu). Pokud neprobíhá žádná komunikace, je handsfree vypnuté. Možnosti volání v kombinaci s GSM komunikátorem GD-06 jsou popsány v jeho manuálu.

Technické parametry

Napájení:	12 V ss ± 25%
Maximální odběr při volání:	1 A
Rozsah pracovních teplot	-20 až +70 °C

HF-03 sada handsfree



Obsah balení

- jednotka Handsfree s přípojovacím konektorem
- mikrofon s konektorem
- drobný instalační materiál

Instalace

Jednotka: vyberte vhodné umístění pro instalaci jednotky HF-03. Vhodné je takové místo, aby přední strana handsfree s reproduktorem směřovala co nejvíce do prostoru (u vozu směrem k řidiči). Nevhodné umístění může výrazně utlumit hlasitost reproduktoru. Při výběru umístění mějte také na paměti délku přívodních vodičů. Jednotku upevněte pomocí přiložené samolepky na dobře odmaštěný povrch. Vodič s šestipólovým RJ konektorem přiveďte k jednotce autoalarmu či GSM komunikátoru a připojte do konektoru určeného pro připojení handsfree.

Mikrofon: vyberte vhodné místo pro mikrofon. U vozidel je optimální vzdálenost cca. 40 – 50 cm od řidičových úst. Pro uchycení mikrofonu je možno použít přiložený klips. Kabel svedte k jednotce a připojte ho do konektoru na boční straně jednotky handsfree.

Nastavení

Tahový potenciometr na jednotce handsfree nastavte vždy na maximum. Citlivost mikrofonu a hlasitost reproduktoru je možno upravit pomocí nastavovacích parametrů výrobku, ve kterém je HF-03 připojeno.

Sada HF-03 slouží k rozšíření funkcí autoalarmu CA-120x Athos nebo GSM komunikátoru GD-06 o možnost telefonování. Instalací této sady k autoalarmu získáte možnost přijímat hovory z libovolných telefonních čísel a možnost volání až na 4 přednastavená telefonní čísla. V době poplachu je možno pomocí sady odposlouchávat prostor vozu a případně i komunikovat s narušitelem. Obsluha handsfree je blíže popsána v manuálu autoalarmu. Sada HF-03 je určena k instalaci do interiéru vozu. Handsfree je aktivováno v případě, že je voláno z vozu nebo pokud je přijímán příchozí hovor (napájení řízeno z autoalarmu). Pokud neprobíhá žádná komunikace, je handsfree vypnuté. Možnosti volání v kombinaci s GSM komunikátorem GD-06 jsou popsány v jeho manuálu.

Technické parametry

Napájení:	12 V ss ± 25%
Maximální odběr při volání:	1 A
Rozsah pracovních teplot	-20 až +70 °C



Pod Skalkou 33
466 01 Jablonec nad Nisou

Tel.: 483 559 911
fax: 483 559 993
Internet: www.jablotron.cz



Pod Skalkou 33
466 01 Jablonec nad Nisou

Tel.: 483 559 911
fax: 483 559 993
Internet: www.jablotron.cz

HF-03 hands-free set



how to set up and use the HF-03 with a GSM communicator, please look at the GD-06 manual.

The kit contents

- hands-free unit
- microphone
- stick-on Velcro

Installation

Unit: Install the unit onto a strictly oil-free surface using the stick-on Velcro provided so that the speaker is oriented towards the driver (in the car) and it is not shielded by any obstacles (remember to take the length of the wire into the consideration). Improper positioning of the unit will result in reduced loudness. Connect the wire with the RJ connector to the CA-120x or GD-06.

Microphone: Fix the microphone to the desired position using the enclosed clips. The optimal position in the car is 40 to 50 cm from the driver's mouth. Plug the jack connector into the socket named MIC, which is located on the side of the main unit.

Setting up

We recommend setting the potentiometer on the top of HF-03 to maximum. It is possible to set the sensitivity of the microphone and the speaker in the device to which the HF-03 is connected.

The HF-03 hands-free set is designed as an optional device for the Athos CA-120x car alarm or the GD-06 GSM communicator. Using the HF-03 you can answer incoming phone calls. It is also possible to call up to four phone numbers. When there is an alarm it is possible to activate listening-in mode or to communicate with anyone near the HF-03 (please see the manual for the GD-06 or the CA-120X for details). If used with the CA-120X the HF-03 should be installed in the interior of the car. The hands-free is only activated if there is a phone call (The HF-03's power supply is controlled by the car alarm). If there is no communication, the HF-03 is switched off. For information about

Specification

Power supply voltage:	12 V DC \pm 25%
Current consumption:	max. 1 A
Working temperature:	-20 °C to +70 °C



Pod Skalkou 33
466 01 Jablonec nad Nisou

Tel.: 483 559 911
fax: 483 559 993
Internet: www.jablotron.cz

HF-03 hands-free set



how to set up and use the HF-03 with a GSM communicator, please look at the GD-06 manual.

The kit contents

- hands-free unit
- microphone
- stick-on Velcro

Installation

Unit: Install the unit onto a strictly oil-free surface using the stick-on Velcro provided so that the speaker is oriented towards the driver (in the car) and it is not shielded by any obstacles (remember to take the length of the wire into the consideration). Improper positioning of the unit will result in reduced loudness. Connect the wire with the RJ connector to the CA-120x or GD-06.

Microphone: Fix the microphone to the desired position using the enclosed clips. The optimal position in the car is 40 to 50 cm from the driver's mouth. Plug the jack connector into the socket named MIC, which is located on the side of the main unit.

Setting up

We recommend setting the potentiometer on the top of HF-03 to maximum. It is possible to set the sensitivity of the microphone and the speaker in the device to which the HF-03 is connected.

The HF-03 hands-free set is designed as an optional device for the Athos CA-120x car alarm or the GD-06 GSM communicator. Using the HF-03 you can answer incoming phone calls. It is also possible to call up to four phone numbers. When there is an alarm it is possible to activate listening-in mode or to communicate with anyone near the HF-03 (please see the manual for the GD-06 or the CA-120X for details). If used with the CA-120X the HF-03 should be installed in the interior of the car. The hands-free is only activated if there is a phone call (The HF-03's power supply is controlled by the car alarm). If there is no communication, the HF-03 is switched off. For information about

Specification

Power supply voltage:	12 V DC \pm 25%
Current consumption:	max. 1 A
Working temperature:	-20 °C to +70 °C



Pod Skalkou 33
466 01 Jablonec nad Nisou

Tel.: 483 559 911
fax: 483 559 993
Internet: www.jablotron.cz